




AUTOMATIC ENTRANCE SPECIALISTS

# CROSS7E / 8E / 14E - E1A QUICK REFERENCE


IP2012  
rev. 2008-10-01

⚠ Before installing the product, carefully read the instructions.



## 1. ELECTRICAL CONNECTIONS FOR STANDARD INSTALLATION



## 2. USAGE WITH STOP LIMIT SWITCH




		DIP2=OFF
1°		Opening limit switch setting
2°		Closing limit switch setting




		DIP2=ON
1°		Opening limit switch setting
2°		Closing limit switch setting


### 3. E1A STANDARD SETTING



### 4. RADIO ENABLING



### 5. AUTOMATIC CLOSING SETTING



For different setting and further information consult the CROSS7E/8E and CROSS14E automation instruction manual, the E1A control panel instruction manual and BIXLR22 radio instruction manual.

DITEC S.p.A.  
Via Mons. Banfi, 3 - 21042 Caronno Pertusella (VA) - ITALY  
Tel. +39 02 963911 - Fax +39 02 9650314  
www.ditec.it - ditec@ditecva.com